



Blue Star AutoHarmony Transmitter samochodowy Bluetooth FM



Instrukcja obsługi

1. Specyfikacja

Marka: Blue Star
Model: C81
Wersja Bluetooth: 5.3
Zasięg Bluetooth: ok. 8 m
Wsparcie protokołów: AVRCP, HFP, A2DP
Zakres częstotliwości: 87.6–107.9 MHz
Napięcie: 12–24 V
Moc: max. 42 W
Wymiary wyświetlacza: 20 × 8 mm
Wymiary transmitera: 36 × 36 × 83 mm
Waga: 45,8 g
Materiał: Aluminium i ABS

2. Funkcje

- b** Naciśnij raz: Zmiana efektów dźwiękowych (b0 – tryb normalny, b1 – zwiększenie basu)
- CH** Tryb muzyki:
Naciśnij raz: Pauza/Odtwórz
Naciśnij dwa razy i obróć głowicę w prawo: Następna piosenka
Naciśnij dwa razy i obróć głowicę w lewo: Poprzednia piosenka
Obróć głowicę w lewo: Zmniejsz głośność
Obróć głowicę w prawo: Zwiększ głośność
Tryb połączeń:
Naciśnij raz: Odbierz/Rozłącz się
Naciśnij i przytrzymaj: Odrzuć połączenie przychodzące / Przełącz na rozmowę prywatną
Tryb strojenia:
Obróć w prawo: Zwiększ częstotliwość
Obróć w lewo: Zmniejsz częstotliwość

CH

Naciśnij krótko: ustaw urządzenie na tryb FM
Naciśnij i przytrzymaj przez 2 sekundy: włącz/wyłącz urządzenie (zachowując możliwość ładowania sprzętu)

3. Sposób użycia

KORZYSTANIE Z TRYBU FM

Przełącz radio samochodowe na niezajętą częstotliwość FM, naciśnij przycisk CH i dostosuj częstotliwość transmitera, aby urządzenie i radio samochodowe pracowały na tym samym poziomie.

KORZYSTANIE Z BLUETOOTH

Aktywuj Bluetooth w swoim telefonie, a następnie wyszukaj nowe urządzenie o nazwie „C81”. Kliknij, aby się połączyć. Podczas połączenia przychodzącego urządzenie automatycznie przełączy tryb.

KORZYSTANIE Z FUNKCJI ŁADOWANIA

Gdy transmitter jest zasilany z gniazda zapalniczki samochodowej, podłącz telefon lub inne urządzenie do jednego z portów (USB-C / USB-A) za pomocą kabla (nie jest dołączony do zestawu), aby rozpocząć ładowanie.

4. Środki ostrożności

Przed użyciem produktu zapoznaj się ze wszystkimi ostrzeżeniami dotyczącymi instrukcji bezpieczeństwa. Niewłaściwe użycie może spowodować uszkodzenie. Aby mieć pewność, że urządzenie działa prawidłowo, nigdy nie używaj go w wilgotnych warunkach, w pobliżu grzejnika lub w wysokiej temperaturze, przy bezpośrednim lub silnym nasłonecznieniu. Nigdy nie demontuj samodzielnie.

Wyprodukowano w CHRL dla Partner Tele.com Sp. z o.o. Sp. k., ul. Sołtysowska 22, 31- 589 Kraków, Polska.



Blue Star AutoHarmony Bluetooth FM Car Transmitter



User Manual

1. Specification

Brand: Blue Star
Model: C81
Bluetooth version: 5.3
Bluetooth distance: approx. 8 m
Protocols support: AVRCP, HFP, A2DP
Frequency range: 87.6–107.9 MHz
Output: max. 42 W
Screen size: 20 × 8 mm
Transmitter size: 36 × 36 × 83 mm
Weight: 45.8 g
Material: Aluminum & ABS

2. Functions

- b** Press once: Switch sound effects (b0 – normal mode, b1 – bass boost)
- CH** Music Mode:
Press once: Pause/Play
Press twice and rotate the knob clockwise: Next song
Press twice and turn the knob anticlockwise: Previous song
Turn the knob anticlockwise: Decrease the volume
Turn the knob clockwise: Increase the volume
Calling Mode:
Press once: Answer/Hang off a call
Press and hold: Reject incoming call/Switch to private call
Tuning Mode:
Rotate clockwise: Increase the frequency
Rotate left: Decrease the frequency
Voice assistant activation (Siri/Google): Press and hold for 2 seconds

CH

Short press to set the device to FM mode.
Press and hold for 2 seconds to turn the device on/off (while still charging).

3. How to use

USING THE FM TRANSMITTER FUNCTION

Turn your car radio to an unoccupied FM frequency, press the CH button and adjust the frequency to make the device and car radio on the same level.

USING THE BLUETOOTH FUNCTION

Activate your mobile phone's Bluetooth function, then search for the new "C81" device. Click to connect. When there is an incoming call, this device automatically switches modes.

USING THE CHARGING FUNCTION

When the transmitter is powered from the car cigarette lighter socket, connect your phone or other device to one of the ports (USB-C / USB-A) using a cable (not included) to start charging.

4. Precautions

Please read all safety instruction warnings carefully before using this product. Improper use of may result in damage. To ensure it work well, please never use the device in moist, underwater, or with direct and strong sunshine conditions, as well as near heater or high-temperature service. Never dismantle the product without due permission.

Made in PRC for Partner Tele.com Sp. z o.o. Sp. k., ul. Sołtysowska 22, 31- 589 Kraków, Poland.